

3085 Deluxe Noid Lite / AC Test Kit



- Expanded set of eight specific noid lites for testing GM PFI, FORD TBI, GEO TBI, BOSCH PFI, GM TBI, GM SCPI and new applications of bosch 2 and multtec 2, fiber optic noid life extension.
- Made in Taiwan