

# 9161 C.V Boot Clamp Plier



- For all ear type clamps.
- Application: For AUDI, BMW, FORD, GM, HONDA, MAZDA, MERCEDES, NISSAN, OPEL, ETC.
- Design to use with 1/2" Dr Extension Handle or Torque Wrench.
- Made In Taiwan