

9280 C.V Joint Banding Tool (with Ratchet and Cutter)



- Installs low-profile clamps used to hold CV boots on most FWD vehicles.
- Ratcheting action & built-in cutter to tighten the clamp quickly and properly.
- Made In Taiwan