

1153 Car Battery & Alternator Checker



- LED lights indicate car battery condition (engine stop) or output of alternator (engine running).
- Lights show poor, fair or good condition.
- Magnetic backboard keeps your hands free for checking.