3074 OHV Valve Spring Compressor



- Permits valve spring and valve stem oil seal to be replaced without the need to remove the cylinder head when used in conjunction with VS1601 compressed air adaptor.
- Reversible jaw adaptor and automatic cam action lock to pre-set spring tension.
- Suitable for use on a wide range of OHV, OHC and CVH engines. NOTE: NOT SUITABLE FOR DEEP SEATED VALVE ENGINE