

3332 BMW M47 Injection Pump Extractor



- To lock the injection pump sprock in position and press out the injection pump shaft.
- This tools is required when removing the injection pump.
- Applicable: BMW M47, M47TU, M57, M57TU engines.
- Made In Taiwan