

G9165 Glatt Double Shaft Bearing Remover



- Use on both internal and external bearings.
- Removing the ball keeper first, and then pick suitable jaws for removing the bearing.
- Jaw diameter: 5,4,6,8
- Made In China